


SPINNING REEL

CETUS

SB500



Key NO.

Parts No.

Parts name

2-8	2YT-140-03	SPOOL TOTAL ASSEMBLY
1	2YD-035-03	DRAG KNOB ASSEMBLY
2	2E4-017-01	DRAG WASHER RETAINER
3	2W2-031-01	KEY WASHER
4	2W1-101-01	064-124 WASHER
5	2YS-081-03	SPOOL ASSEMBLY
6	2L2-015-01	CLICK PAWL
7	2E5-020-01	E1.5 RETAINER
8	2Q2-015-01	CLICK PAWL SPRING
9	2W1-097-02	059-100 WASHER
10	2F3-038-01	CLICK GEAR
11	2M1-029-01	OSCILLATING SLIDER
12	2E2-030-01	F20M-050 SCREW
13	2E3-001-01	ROTOR NUT
14	2C3-027-01	ROTOR NUT RETAINER
15	2R1-065-03	ROTOR
16	2R4-080-02	BAIL TRIP COVER
17	2E1-016-03	B26-080 SCREW
18	2R5-081-01	BAIL TRIP LEVER A
19	2R5-082-01	BAIL TRIP PLATE
20	2Q3-084-01	BAIL TRIP LEVER SPING
21	2R5-083-01	BAIL TRIP LEVER B
22	2F5-130-03	ROTOR COVER
23	2E1-020-01	B22-055 SCREW
24	2E2-018-02	B30M-080 SCREW
25	2R2-028-01	BAIL ARM
26	2E1-037-02	B30-080 SCREW
27	2C1-056-01	LINE ROLLER COLLAR

Key NO.

Parts No.

Parts name

28	2Z1-012-02	407-2.5 BALL BEARING
29	2R6-012-01	LINE ROLLER
30	2C2-032-01	LINE ROLLER BUSH
31	2YL-075-02	BAIL ASSEMBLY
32	2Q1-051-01	BAIL SPRING
33	2R4-088-02	BAIL SPRING COVER
34	2A4-040-01	ONE-WAY CLUTCH INNER TUBE
35	2YZ-012-01	ONE-WAY CLUTCH BEARING ASSY
36	2Z1-006-01	613-3.5 BALL BEARING
37	2G2-043-01	PINION GEAR
38	2E1-052-01	A20-130 SCREW
39	2Q3-009-01	ANTI-REVERSE SPRING
40	2A2-040-01	ANTI-REVERSE CAM
41	2B1-044-03	BODY
42	2A1-022-01	ANTI-REVERSE LEVER
43	2E2-013-03	B20M-060 SCREW
44	2Z1-009-01	711-3 BALL BEARING
45	2G1-028-01	DRIVE GEAR
46	2M2-001-01	OSCILLATING SLIDER
47	2W1-019-00	071-103 WASHER
48	2Z1-002-01	714-3.5 BALL BEARING
49	2B2-032-03	BODY COVER
50	2E1-005-03	A26-120 SCREW
51	2YH-117-01	HANDLE TOTAL ASSEMBLY
52	2W1-004-01	029-080 WASHER
53	2H6-016-02	HANDLE SCREW CAP
54	2F5-077-02	REAR COVER