



Key	Parts No.	Parts name	Key	Parts No.	Parts name
1	2YD-130-01	DRAG KNOB ASSEMBLY	34	2E1-045-01	A26-080 SCREW
2	2YT-603-01	SPOOL TOTAL ASSEMBLY	35	2Z1-005-07	816-5 BALL BEARING
3	2E4-009-01	DRAG WASHER RETAINER	36	2C1-148-02	BUSHING
4	2W2-010-02	KEY WASHER	37	2A4-082-02	ONE-WAY CLUTCH INNER TUBE
5	2W1-052-03	050-187 WASHER	38	2YZ-027-02	ONE-WAY CLUTCH BEARING ASSEMBLY
6	2W3-003-01	EARED WASHER	39	2Q2-027-01	SPRING
7	2S1-505-01	SPOOL	40	2G2-205-01	PINION GEAR
8	2Q3-121-01	SPRING	41	2A2-128-01	ANTI-REVERSE CAM
9	2S4-019-01	LINE STOPPER	42	2Q3-087-01	ANTI-REVERSE SPRING
10	2L2-018-01	CLICK PAWL	43	2A1-036-05	ANTI-REVERSE LEVER
11	2Q3-136-01	CLICK PAWL SPRING	44	2E2-099-01	B20M-050 SCREW
12	2E8-001-01	STAR WASHER	45	2YB-287-01	BODY ASSEMBLY
13	2W2-101-04	KEY WASHER	46	2F6-145-01	OSCILLATING SLIDER COVER
14	2F3-077-03	CLICK GEAR	47	2E1-075-01	B22-045 SCREW
15	2E3-002-01	ROTOR NUT	48	2G3-102-01	OSCILLATING GEAR
16	2E1-036-01	B26-040 SCREW	49	2M1-089-01	OSCILLATING SILDER
17	2R1-187-01	ROTOR	50	2E2-009-02	F23M-060 SCREW
18	2R5-230-01	BAIL PAWL	51	2F5-548-01	REAR COVER
19	2R5-203-01	BAIL TRIP SHAFT	52	2Z1-009-07	711-3 BALL BEARING
20	2Q1-141-01	BAIL SPRING	53	2G1-069-02	DRIVE GEAR
21	2R4-257-01	BAIL SPRING COVER	54	2W1-019-00	071-103 WASHER
22	2E1-070-02	B22-065 SCREW	55	2Z1-004-07	814-3.5 BALL BEARING
23	2E1-025-01	b30-080 SCREW	56	2YC-128-01	BODY COVER ASSEMBLY
24	2R2-098-01	BAIL ARM	57	2E1-045-01	A26-080 SCREW
25	2E2-018-01	B30M-080 SCREW	58	2YH-545-01	HANDLE TOTAL ASSEMBLY
26	2C1-034-01	LINE ROLLER COLLAR	59	2C3-042-01	HANDLE SCREW SLEEVE
27	2Z1-012-05	407-2.5 BALL BEARING	60	2H6-023-01	HANDLE SCREW CAP
28	2R6-020-01	LINE ROLLER			
29	2C2-032-01	LINE ROLLER BUSH	GNBT3000	SPECIAL PARTS	
30	2YL-219-01	BAIL ASSEMBLY	2	2YT-604-01	SPOOL TOTAL ASSEMBLY
31	2W1-291-01	081-110 WASHER	7	2S1-506-01	SPOOL
32	2M3-197-01	MAIN SHAFT	52	2Z1-009-05	711-3 BALL BEARING
33	2F5-519-01	ROLLER CLUTCH RETAINER	55	2Z1-004-05	814-3.5 BALL BEARING