



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-089-15	DRAG KNOB ASSEMBLY	31	2E1-050-01	A20-060 SCREW
2	2E4-034-01	DRAG WASHER RETAINER	32	2Q2-016-01	SPRING
3	2W2-071-01	KEY WASHER	33	2F5-398-01	ROLLER CLUTCH RETAINER
4	2W1-226-02	080-260 WASHER	34	2YZ-019-01	ONE-WAY CLUTCH BEARING ASSEMBLY
5	2YT-527-01	SPOOL TOTAL ASSEMBLY	35	2E1-063-01	F26-070 SCREW
6	2W2-016-01	KEY WASHER	36	2F5-212-01	BEARING RETAINER
7	2Z1-029-05	408-3 BALL BEARING	37	2Z1-003-05	714-5 BALL BEARING
8	2C1-119-01	SPACER	38	2G2-131-01	PINION GEAR
9	2L3-014-01	CLICK LEAF SPRING	39	2A2-088-01	ANTI-REVERSE CAM
10	2W1-053-01	080-185 WASHER	40	2Q3-102-01	ANTI-REVERSE SPRING
11	2M3-172-01	MAIN SHAFT	41	2G3-102-01	OSCILLATING GEAR
12	2F8-013-01	CLICK LEAF SPRING HOLDER	42	2M1-084-01	OSCILLATING SILDER
13	2W2-015-01	KEY WASHER	43	2E2-009-02	F23M-060 SCREW
14	2E3-007-01	ROTOR NUT	44	2A1-034-11	ANTI-REVERSE LEVER
15	2E1-036-01	B26-040 SCREW	45	2E2-013-02	B20M-060 SCREW
16	2R1-164-01	ROTOR	46	2C3-042-01	HANDLE SCREW SLEEVE
17	2E2-018-03	B30M-080 SCREW	47	2H6-017-02	HANDLE SCREW CAP
18	2R2-079-01	BAIL ARM	48	2YB-269-01	BODY ASSEMBLY
19	2C1-034-01	LINE ROLLER COLLAR	49	2Z1-009-05	711-3 BALL BEARING
20	2Z1-012-05	407-2.5 BALL BEARING	50	2G1-069-01	DRIVE GEAR
21	2R6-020-02	LINE ROLLER	51	2W1-019-00	071-103 WASHER
22	2C2-032-01	LINE ROLLER BUSH	52	2Z1-004-05	814-3.5 BALL BEARING
23	2YL-193-01	BAIL ASSEMBLY	53	2B2-145-01	BODY COVER
24	2E1-025-01	b30-080 SCREW	54	2E1-055-01	A26-100 SCREW
25	2R5-203-01	BAIL TRIP SHAFT	55	2YH-280-03	HANDLE TOTAL ASSEMBLY
26	2Q1-141-01	BAIL SPRING	56	2F6-137-01	OSCILLATING SILDER GUIDE
27	2R5-204-01	BAIL PAWL	57	2F5-467-01	REAR COVER
28	2R4-219-01	BAIL SPRING COVER	GP2500	SPECIAL PARTS	
29	2E1-065-01	B22-065 SCREW	5	2YT-528-01	SPOOL TOTAL ASSEMBLY
30	2A4-021-01	ONE-WAY CLUTCH INNER TUBE			