




SPINNING REEL

GAMMA

GGUT3000



KEY NO.	Parts No.	Parts name
1	2YD-089-23	DRAG KNOB ASSEMBLY
2	2E4-034-01	DRAG WASHER RETAINER
3	2W2-071-01	KEY WASHER
4	2W1-226-01	080-260 WASHER
5	2W3-035-01	EARED WASHER
6	2YT-486-02	SPOOL TOTAL ASSEMBLY
7	2W2-020-01	KEY WASHER
8	2L3-015-01	CLICK LEAF SPRING
9	2F8-019-02	CLICK LEAF SPRING HOLDER
10	2W2-015-01	KEY WASHER
11	2E3-094-01	ROTOR NUT
12	2E1-036-01	B26-040 SCREW
13	2E1-015-02	B26-060 SCREW
14	2R4-215-02	BAIL TRIP COVER
15	2R5-189-01	BAIL PAWL
16	2R1-152-05	ROTOR
17	2R5-040-01	BAIL TRIP SHAFT
18	2W1-044-01	016-035 WASHER
19	2Q1-132-02	BAIL SPRING
20	2R4-214-02	BAIL SPRING COVER
21	2E1-025-01	b30-080 SCREW
22	2YL-163-01	BAIL ASSEMBLY
23	2C2-032-01	LINE ROLLER BUSH
24	2R6-020-02	LINE ROLLER
25	2Z1-012-06	407-2.5 BALL BEARING
26	2C1-034-01	LINE ROLLER COLLAR
27	2R2-062-13	BAIL ARM
28	2E2-007-01	B30M-100 SCREW
29	2E1-050-01	A20-060 SCREW
30	2F5-436-01	ROLLER CLUTCH RETAINER
31	2A4-082-01	ONE-WAY CLUTCH INNER TUBE

KEY NO.	Parts No.	Parts name
32	2M3-167-01	MAIN SHAFT
33	2YZ-027-01	ONE-WAY CLUTCH BEARING ASSEMBLY
34	2Q2-021-01	SPRING
35	2W1-268-01	130-215 WASHER
36	2E1-077-01	F30-080 SCREW
37	2F5-419-01	BEARING RETAINER
38	2C1-135-01	PINION GEAR BUSH
39	2Z1-005-06	816-5 BALL BEARING
40	2G2-183-01	PINION GEAR
41	2A2-117-01	ANTI-REVERSE CAM
42	2Z1-009-06	711-3 BALL BEARING
43	2G1-150-01	DRIVE GEAR
44	2W1-035-00	080-105 WASHER
45	2Z1-023-06	814-4 BALL BEARING
46	2B2-140-05	BODY COVER
47	2E1-055-01	A26-100 SCREW
48	2YH-347-06	HANDLE TOTAL ASSEMBLY
49	2B1-195-05	BODY
50	2H6-017-02	HANDLE SCREW CAP
51	2C3-042-01	HANDLE SCREW SLEEVE
52	2E2-099-01	B20M-050 SCREW
53	2L5-010-01	ANTI-REVERSE CAM SPRING
54	2A1-037-07	ANTI-REVERSE LEVER
55	2M2-016-01	OSCILLATING CAM
56	2G3-081-01	OSCILLATING GEAR
57	2M1-081-01	OSCILLATING SILDER
58	2E2-009-02	F23M-060 SCREW
59	2F6-130-01	CLUTCH PAWL RETAINER
60	2E1-070-02	B22-065 SCREW
61	2F5-587-01	REAR COVER
62	2E1-015-02	B26-060 SCREW