


SPINNING REEL

GCA800

Please order by parts number, not key number
 Bitte, Best-Nr. angeben (Nicht "key" -nr.)
 Veuillez indiquer le numero de la piece (Non "key" no.)



KEY NO.	Parts No.	Parts name	KEY NO.	Parts No.	Parts name
1	00A-AX1-01	DRAG KNOB ASSY.	25	00A-AX1-25	BALL BEARING (061203)
2	00A-AX1-02	SIX CORNER SPRING	26	00A-AX1-26	BALL BEARING BUSHING
3	00A-AX1-03	KEY WASHER	27	00A-AX1-27	ONE WAY CLUTCH ASSY
4	00A-AX1-04	DRAG WASHER	28	00A-AX1-28	PINIOR GEAR
5	00A-AX1-05	BODY CAP	29	00A-AX1-29	ONE WAY CLUTCH SCREW
6	00A-AX1-06	S POOL ASSY	30	00A-AX1-30	BODY
7	00A-AX1-07	C LICK GEAR WASHER	31	00A-AX1-31	HANDLE SCREW WASHER
8	00A-AX1-08	C LICK GEAR WASHER	32	00A-AX1-32	HANDLE SCREW
9	00A-AX1-09	MAIN SHAFT	33	00A-AX1-33	ANTI-REVERSE LEVEL
10	00A-AX1-10	ROTOR NUT	34	00A-AX1-34	BALL BEARING (071103)
11	00A-AX1-11	WASHER	35	00A-AX1-35	DRIVE GEAR
12	00A-AX1-12	ROTOR	36	00A-AX1-36	WASHER
13	00A-AX1-13	LINE ROLLER SCREW	37	00A-AX1-37	BALL BEARING (071404)
14	00A-AX1-14	BAIL ARM	38	00A-AX1-38	BODY COVER
15	00A-AX1-15	BAIL ASSY SCREW	39	00A-AX1-39	BODY COVER SCREW
16	00A-AX1-16	WASHER	40	00A-AX1-40	HANDLE ASSY
17	00A-AX1-17	LINE ROLLER	41	00A-AX1-41	SLIDER
18	00A-AX1-18	BAIL ASSY	42	00A-AX1-42	SILDER SCREW
19	00A-AX1-19	SCREW	43	00A-AX1-43	OSCILLATION GEAR SCREW
20	00A-AX1-20	ROTOR COVER SCREW	44	00A-AX1-44	OSCILLATION GEAR
21	00A-AX1-21	COMPRESSION SPRING	45	00A-AX1-45	BODY CAP SCREW
22	00A-AX1-22	BAIL ARM YORK	46	00A-AX1-46	ANTI-REVERSE SPRING
23	00A-AX1-23	CLICK LEVEL	47	00A-AX1-47	ANTI-REVERSE SCREW
24	00A-AX1-24	BALL BEARING COVER	48	00A-AX1-48	ANTI-REVERSE BUTTON