




# SALTWATER REEL

# TYA5L/TYA5HL



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2E0-006-03	X26M-045 SCREW	43	2P1-078-01	ANTI-REVERSE PAWL PIN
2	2F6-043-01	ROTOR NUT HOLDING PLATE	44	2E2-092-01	B20M-050 SCREW
3	2E3-027-02	HANDLE NUT	45	2F5-572-01	DUST COVER
4	2W1-075-02	051-100 WASHER	46	2Q1-144-01	YOKE SPRING
5	2YH-572-01	HANDLE TOTAL ASSEMBLY	47	2G2-206-01	PINION GEAR
6	2W2-044-01	KEY WASHER	48	2A2-137-01	PINION YOKE
7	2YD-139-01	STAR DRAG LEVER ASSY	49	2E2-044-01	A20M-050 SCREW
8	2L1-025-01	SPRING WASHER	50	2F8-159-01	CLUTCH CAM RETAINER
9	2L3-058-01	CLICK LEAF SPRING	51	2A2-136-01	CLUTCH CAM
10	2F8-147-01	CLICK LEAF SPRING HOLDER	52	2A4-103-01	CLUTCH PAWL
11	2E9-063-01	PROOF WATER RING	53	2Q3-138-01	CLUTCH PAWL SPRING
12	2W1-035-06	080-105 WASHER	54	2Z1-010-02	812-3.5 BALL BEARING
13	2Z1-004-02	814-3.5 BALL BEARING	55	2YB-296-01	BODY ASSEMBLY
14	2W2-043-01	KEY WASHER	56	2C4-031-01	CASTING BAR GUIDE
15	2E2-050-01	A20M-035 SCREW	57	2E1-059-01	F20-060 SCREW
16	2F5-570-01	REAR COVER	58	2S3-041-01	CASTING BUTTON
17	2F5-589-01	RING B	59	2YT-619-01	SPOOL TOTAL ASSEMBLY
18	2YD-138-01	DRAG KNOB ASSEMBLY	60	2F3-087-01	CLICK GEAR
19	2W5-079-04	CAST CONTROL SPACER	61	2E2-099-01	B20M-060 SCREW
20	2L3-061-01	CLICK LEAF SPRING	62	2E2-092-01	B20M-050 SCREW
21	2E4-019-01	BEARING RETAINER	63	2F8-161-01	FIXER
22	2Z1-001-02	508-2.5 BALL BEARING	64	2Q1-014-01	CLICK PIN SPRING
23	2E9-062-01	O RING	65	2YD-137-01	MAGNET ASSEMBLY
24	2E2-107-01	H20M-080 SCREW	66	2E2-103-01	F20M-030 SCREW
25	2YF-213-01	LEFT SIDE PAWL ASSEMBLY	67	2F3-088-01	DRAG KNOB CLICK NUT
26	2E4-021-01	DRAG WASHER RETAINER	68	2D1-102-01	BRAKE ADJUSTING KNOB
27	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY	69	2E4-011-01	BEARING RETAINER
28	2A4-026-01	ONE-WAY CLUTCH INNER TUBE	70	2Z1-022-02	410-4 BALL BEARING
29	2W2-096-02	KEY WASHER	71	2W5-079-04	CAST CONTROL SPACER
30	2W1-296-01	082-345 WASHER	72	2E5-006-01	E2.5 RETAINER
31	2W3-044-01	EARED WASHER	73	2F4-026-01	CLICK PAWL
32	2W2-096-01	KEY WASHER	74	2Q2-028-01	SPRING
33	2G1-186-01	DRIVE GEAR	75	2E0-068-01	SCREW
34	2W1-090-03	082-260 WASHER	76	2L5-030-01	CLICK PLATE
35	2A3-051-01	RATCHET	77	2F5-573-01	RIGHT SIDE COVER
36	2M3-194-01	DRIVE SHAFT	78	2W5-040-02	CLICK SWITCH WASHER
37	2E2-009-02	F23M-060 SCREW	79	2F7-014-01	CLICK SWITCH
38	2W1-070-03	052-080 WASHER			
39	2F6-149-01	DRIVE SHAFT RETAINER			
40	2E5-013-01	E3.0 RETAINER			
41	2Z1-017-02	509-3 BALL BEARING			
42	2YA-045-01	ANTI-REVERSE PAWL ASSEMBLY			